

- Screwdriver

LUXOR AV26 Instructions 26" Two-Shelf Steel AV Cart


PARTS LIST:




ASSEMBLY INSTRUCTIONS:




- · Flip the shelf unit upside down on a carpet or other nonscratch surface.
- Insert the non-locking casters (C) into the wheel sockets on one of the narrow ends
- Insert the locking casters (D) into the wheel sockets on the opposite end.



- Push the bolts (G) through the corresponding holes in the power strip (E).
- Push the bolts through the corresponding holes in the cord wrap (F).
- Push the bolts through the power strip mount holes at end of top shelf.
- Use the wing nuts (H) and screwdriver to fasten power strip and cord wrap to the cart.



- Flip the shelf unit back over.
- Ensure the mat is correctly in place on your desired shelf.
- Select a set of power strip mount holes at one of the narrow ends of the top shelf.



- Unlock the casters to allow the wheels to spin freely.
- Lock the casters to keep the cart in place.