

A

Top

C


Middle

B

Bottom

Tub Shelves*

(SEC, EC, STC, and TC models)



A

Top

C


Middle

B


Bottom

Flat Shelves*


(BC, HE, HC, LE, LP, and WT models)




D x 2




F x 2




G x 2




H x 1



I x 16



J x 16




K x 16

4" Standard Casters

(All models except for ECHD and XLC)

5" Heavy-Duty Casters + Hardware


(ECHD and XLC models)



L

Square Legs


(WT, SEC, and EC models)



L

Round Legs

(LE, LP, STC, TC, and BC models)





L

Fluted Legs

(XLC and all models with cabinet pack)

REQUIRED TOOLS:

 Rubber Mallet
(Not included)

 Phillips Head Screwdriver
(ECHD and XLC models only, not included)


IMPORTANT:

If your cart includes options such as a power strip, pullout shelf, locking drawer, or locking cabinet, installation instructions for those components will be included in their packaging.


*NOTE:

Some BC, STC, and TC models come with a mix of flat and tub shelves.


OPTIONAL ACCESSORIES: (If your cart includes one or more of the optional accessories shown below, separate installation instructions are enclosed with each accessory.)




Cabinet Pack




Pullout Shelf + Hardware



3-Outlet Power Strip + Hardware



3-Outlet Power Strip with Cord Wrap + Hardware




Locking Drawer + Hardware


WHAT'S IN THE BOX:


Part	Standard 2-Shelf	Standard 3-Shelf	Standard 4-Shelf	Standard 5-Shelf	Standard 6-Shelf	Heavy-Duty 2-Shelf	Heavy Duty 3-Shelf
Top Shelf (A)	1	1	1	1	1	1	1
Bottom Shelf (B)	1	1	1	1	1	1	1
Middle Shelf (C)	0	1	2	3	4	0	1
Locking 4" Caster (D)	2	2	2	2	2	0	0
Non-Locking 4" Caster (E)	2	2	2	2	2	0	0
Locking 5" HD Caster (F)	0	0	0	0	0	2	2
Non-Locking 5" HD Caster (G)	0	0	0	0	0	2	2
Allen Wrench (H)	0	0	0	0	0	1	1
Threaded Insert (I)	0	0	0	0	0	16	16
Threaded Screw (J)	0	0	0	0	0	16	16
Star Washer (K)	0	0	0	0	0	16	16
Legs (L)	4	8	12	16	20	4	8


ASSEMBLY INSTRUCTIONS:


Standard Models


1

2

3

4


5


6


NOTE: Position locking casters (D) on the same end as the handle.


Flip unit upright after casters are securely installed.


Heavy-Duty Models


1

2

3

4


5


6


NOTE: Position locking casters (F) on the same end as the handle.


Flip unit upright after casters are securely installed.


Cabinet Pack Models


1

1a

2

3

4

5

Stop Here! Refer to cabinet assembly instructions, then proceed to step 3.

NOTE: Position the handle on the same end as the locking casters (D).

LUXOR

www.luxorworkspaces.com


Tuffy Cart Cabinet

Pack Instructions

Please consult your Tuffy cart base unit instructions before starting

08/28/23

Parts List




Tools Required


- Rubber Mallet

1


IMPORTANT: Flip shelf B, and lock the 2 locking casters D before assembling the unit.




2




3




4



5




6



Electric Assembly Instructions



Number of outlets
may vary.

Parts List



Tools Required

- Screwdriver



1

Push screw **C** through electric outlet **A**. Make sure the electric outlet **A** and cord wrap **B** align with the mounting surface screw holes. Push screw **C** through cord wrap **B** and the mounting surface screw holes. Use wing nut **D** and screwdriver to fasten.